PumpAlarm.com

TextLight Tank Level Monitoring Kit



Contents











Includes: (1) Bushing (1) TextLight Accessory Bag (1) Backup Battery with Mounting Pocket (1) Tank Level Switch (1) TextLight



NEED MORE GUIDANCE?

For technical support please call:

1-888-454-5051

Hours: Mon- Fri: 8am - 5pm EST



Instructions

- 1 Install level with 1/2" npt fitting on side of tank.
- 2 Connect white wires to orange wires on TextLight.
- 3 Tip float switch and alarm will activate.